

Troubleshooting ThinLINE Torque Wrench Series 150-4

Problem	Possible Causes	Possible Solutions
The Cylinder does not extend or retract	The quick disconnects are not connected properly	Check connections
The quick disconnect will not lock, or will not release	The hydraulic hose is still pressurized	Release the pressure in the hose
The wrench locks up on the bolt	The pawl control lever is jammed	Release the pawl control lever

Storage Tips:

- Fully retract the cylinder.
- Rinse and clean the wrench.
- Lubricate the entire wrench with a light film of oil.